


# Part Numbering for Transducers & Indicators



A) Audio, SM (surface mount)

B) Indicator, Transducer

C1, C2) Diameter or largest dimension

D1, D2) Frequency in KHz

E) Top, Side firing

F) Washable (OPTIONAL)

G) Thru-hole, Flange, Panel

H) Special Connections (OPTIONAL)

-LW(C): Wire length with or without Connector,

-WP for waterproof,

-R for RoHS compliance.

Ex. AI-1224-TWT-R, SMT-1141-T-R, AI-2240-TF-LWC50-R



**Additional  
Information at:**

[www.puiaudio.com/faq](http://www.puiaudio.com/faq)